


# Fitting Instructions for Cord Tension

## How to install the CORD Tension device

The tension device reduces the chance of strangulation by limiting access to the control cord or chain. When fitted properly it should hold any looped controls firmly a wall or window frame. This should make it hard for young children to fit through the controls. Clip the cord through the bottom of the tension. Position the tension device to a Solid wall elements (EG: Masonry, Timber frame and Studs behind plaster wall) should be used as a mounting base for your cord guide. Make sure the control is not twisted when mounting to the wall or frame. DO NOT stretch or pull down on the cord when installing. The cord should be tort and not stretched when installed. By over tensioning this can cause wear out your product. Hold the tension device in the correct position, as shown. Insert and secure the screw through hole. Make sure the screw is affixed into a solid surface. The cord guide shall be mounted at a height of 1600 mm or higher from the floor if the cord guide must be mounted on plasterboard.



## STANDARD – INSTALLATION INSTRUCTIONS

- (a) A statement that, to avoid creating a possible strangulation hazard for children, the corded internal window covering must be installed in such a way that a loose cord cannot form a loop 220 mm or longer at a height of less than 1600 mm above floor level: and

Practical suggestions on how to install the corded internal window covering to ensure compliance with paragraph (a), Including:

- (i) A statement that a cord guide may be installed lower than 1600 mm above floor level if the cord is sufficiently secured or tensioned to prevent a loop 220 mm or longer from being formed: and
- (ii) A statement that if a cord guide is installed lower than 1600 mm above floor level it must be designed to prevent a child from being able to remove the cord: and
- (iii) A statement that if a cleat is used to secure the cord it must be at least 1600 mm above floor level because a child is capable of unwinding a cord from a cleat.

## WARNING



Young children can STRANGLE in cord loops. They can also wrap cords around their necks and STRANGLE. Always keep cords out of children's reach. Move cots, play pens, and other furniture away from cords. Children can climb furniture to get to cords. Attach tension device to walls and floors. This can prevent from pulling cords around their necks